

Non-Destructive Inspection of Composite Wrapped Thick-Wall Cylinders

Jikai Du, John Feldhacker, Christopher Jerred and Fereidoon Delfanian

May 17-19, 2010

Joint Armaments Conference, Exhibition and Firing Demonstration

Materials Evaluation and Testing Laboratory (METLab)
Mechanical Engineering Department, Box 2219 SCEH 214
South Dakota State University, Brookings, SD 57007-0294
Phone: (605) 688-4300, Fax: (605) 688-5878, <http://www.sd-metlab.org>

Introduction


- Compared to all-steel cylinder, composite wrapped cylinder can reduce weight.
- Appropriate evaluation techniques are necessary for the evaluation of cylinder's structural integrity, especially the property of composite layer and the interface condition between composite and steel layer.
- Our research work focus on the experimental and theoretical study of various ultrasound techniques for the inspection of such multilayer cylindrical structures.

How Ultrasound Works

- Ultrasound is acoustic wave with frequency higher than 20 KHz.
- Ultrasound is mechanical wave that can travel in solid media. Its traveling velocity and attenuation are related to material properties such as density and elastic constants.
- When ultrasound propagates in materials, reflection and refraction may occur at acoustic discontinuities such as delaminations and inclusions.

Challenges of the Acoustic Evaluation


- High acoustic attenuation caused by the thick composite layer.
- The complexity of the acoustic propagation in multilayer cylindrical structure.
- Various types of defects: steel layer, composite layer, and steel/composite interface.



Ultrasound C-Scan Technique


Reflection Mode

- Pros: simple system setup and easy signal analysis.
- Cons: high attenuation.





Transmission Mode

- Pros: low attenuation.
- Cons: Complex system setup and difficult signal analysis.





Ultrasound C-Scan System





Steel Layer Ultrasound Signal Calibration

- Transducer: Freq. 10 MHz, dia. 0.25", contact.
- Ultrasound velocity: 0.235 in/ μ sec.





Composite Layer Ultrasound Signal Calibration

- Transducer: Freq. 0.5 MHz, dia. 0.75", unfocused.





C-Scan Transmission Mode System Setup

- Transmitter: Freq. 1.0 MHz, dia. 1.125", unfocused.
- Receiver: Freq. 0.5 MHz, dia. 0.75", unfocused.
- Distance between transmitter and receiver: optimized experimentally.





C-Scan Transmission Mode of Known Defect in Steel Layer(1)

- Defect can be seen in the inner steel layer at the end of the cylinder (see picture).
- The first transmitted acoustic signal was used for imaging.
- C-Scan image size is 360 degrees by 11 inches (about half the length of the cylinder).






C-Scan Transmission Mode of Known Defect in Steel Layer (2)

- Image size: 360 degrees by about 25.0 mm.




C-Scan Reflection Mode of Unknown Defect in Composite Layer

- Reflection mode: 0.5 MHz, dia. 0.75", unfocused.
- Image size: 360 degrees by about 60.0 mm.
- Defect in composite layer can be detected.




Inspection of Composite/Steel Interface


- Drilled hole: diameter 2.5 mm and depth 25.0 mm
- Transducer: Freq. 0.5 MHz, dia. 0.75", unfocused.



Signal train on the hole




Signal train off the hole




C-Scan Imaging of Composite/Steel Interface (1)

- The drilled hole can be imaged by ultrasound C-scan transmission mode.




C-Scan Imaging of Composite/Steel Interface (2)

- The drilled hole can be barely detected with reflection mode.




Ultrasound Guided Wave for Steel Surface Inspection

- The above C-scan technique failed to detect two small steel surface defects: defect 1 at 70 mm from edge and defect 2 at 165 mm from edge.
- Ultrasound guided wave technique with angle beam transducer is applied.
- Various frequencies and incident angles were tested.




Ultrasound Guided Wave for Known Defect


- Ultrasound system: Pocket UT™ system
- Transducer: 3.5 MHz
- Wedge: 60°
- Detection direction: axial direction



Signals at no-defect region




Signals at defect region




Difference

Ultrasound Surface Wave for Surface Defect (1)

- Ultrasound system: Pocket UT™ system
- Transducer: 3.5 MHz
- Wedge: 90°
- Detection direction: axial direction




Signals of defect 1




Reflections from defect 1

Ultrasound Surface Wave for Surface Defect (2)

- Ultrasound system: Pocket UT™ system
- Transducer: 3.5 MHz
- Wedge: 90°
- Detection direction: axial direction



Signals of defect 2





Reflections from defect 2

Summary of Experimental Results





- Defects in both steel layer and composite layer can be imaged by ultrasound C-scan technique.
- Dia. 2.5mm drilled hole can be imaged with ultrasound C-scan transmission mode, but cannot be detected with ultrasound C-Scan reflection mode.
- Because of the high acoustic attenuation caused by the composite layer, ultrasound frequency at about 1.0 MHz is applied.
- Ultrasound guided wave with 60⁰ angle beam transducer is suitable for detecting defects from long distance.
- Ultrasound surface wave with 90⁰ angle beam transducer is sensitive to surface small defects which may be difficult for C-Scan imaging technique.

Ultrasound Simulation with CIVA

- CIVA is an ultrasound simulation software that can simulate acoustic wave propagation and its interaction with flaws.
- CIVA can simulate with both single element acoustic sensor and phased array acoustic sensors




Ultrasound Simulation with Cylindrical Structure (1)





Ultrasound Simulation with Cylindrical Structure (2)

- Longitudinal and shear wave test configuration for a cylindrical structure




Ultrasound Simulation of Flaw Responses





Ultrasound Simulation with Composite Materials (1)

- Orientation and elastic properties of each composite layer can be determined.



Ultrasound Simulation with Composite Materials (2)



- Acoustic attenuation and beam bending can be simulated.



Conclusions

- Various ultrasound techniques have been applied for the evaluation of various types of defects in composite wrapped cylinder.
- The high acoustic attenuation caused by composite can be improved by low ultrasound frequencies, but this needs to be further studied.
- CIVA theoretical simulation may help to understand the ultrasound propagation in cylinder, and to optimize experimental parameters.
- Further quantitative comparison of CIVA simulation and experiments is necessary to improve the sensitivity of ultrasound inspection.
- Other NDE techniques, such as eddy current technique and ultrasound phased array technique, also have the potential for on-site evaluation of cylinders.

Portable Inspection System



Thank You!