

# "State of the Art Fuze Batteries and their Performance"



61<sup>th</sup> Annual Fuze Conference May 15<sup>th</sup> - 17<sup>th</sup>, 2018 Roland Hein Diehl & Eagle Picher GmbH

#### **Overview**



- Introduction of the Design Features of Reserve Batteries
- Reserve Battery Versions
- Reserve Battery Versions Overview
- Reserve Battery Application
- Reserve Battery Testing
- Reserve Battery Versions Summary
- Recommendations for Fuze Electronic Design
- Future developments

# Introduction of the Design Features of Reserve Batteries



- Primary Design Features of all Reserve Batteries
  - Lithium Metal Battery
  - Lithium Thionylchloride electrolyte (LiSOCl<sub>2</sub>)
  - glass ampoule
  - release mechanism/activation mechanism
  - metal to glass seal
  - hermetically sealed stainless steel case
  - 100 % helium leak test



#### **Reserve Battery - Versions**



#### Battery Parameter

Diameter max.: 18,2 mm (0.72 in)

Height: 13,7 mm (0.54 in)

Electrode Area: 1,4 cm² (0.22 in²)

Volume: 1,8 cm<sup>3</sup> (0.11 in<sup>3</sup>)

Diameter max. : 32,2 mm (1.27 in)

Height: 25,5 mm (1.0 in)

Electrode Area: 3,5 cm² (0.54 in²)

Volume: 15 cm<sup>3</sup> (0.92 in<sup>3</sup>)

Diameter : 11 mm (0.43 in)

Height: 11 mm (0.43 in)

Electrode Area: 0,4 cm² (0.06 in²)


Volume: 1,0 cm3 (0.06 in3)




# **Reserve Battery - Versions Overview**



"Large"	"Large"	"Midi"	"Mini"	"Ultra Mini"
DEP14001	DEP14007/17/12	DEP14020/21	DEP14202	DEP14103
5 – 10 cells	5 – 10 cells	1 – 4 cells	1 – 2 cells	1 cell
7 cells	8 cells	2 cells	2 cells	1 cell
25.2 V	28.8 V	7.2 V	7.2 V	3.6 V












#### **Reserve Battery - Application**



#### Reserve Battery in a typical application




1. How much Power does the Fuze Electronic need?

#### **Reserve Battery - Application**



Reserve Battery – Internal Resistance




- 1. How much Power does the Fuze Electronic need?
- 2. What is the minimum Voltage for operating a Fuze Electronic ?

#### **Reserve Battery - Application**



#### Reserve Battery – Equivalent Circuit Diagram



#### **Reserve Battery - Testing**



#### Reserve Battery – Battery-Test-System




#### Flexibel Configuration of

- Acceleration Pulse
- Rotation
- Electrical Load

#### **Reserve Battery - Testing**



#### Reserve Battery – Test Results (Example)





- 1. How much Power may a Fuze Electronic require at what time?
- 2. What is then the minimum Voltage for operating a Fuze Electronic?

# **Reserve Battery - Versions Summary**



"Large"	"Large"	"Midi"	"Mini"	"Ultra Mini"
DEP14001	DEP14007/17/12	DEP14020/21	DEP14202	DEP14103
5 – 10 cells	5 – 10 cells	1 – 4 cells	1 – 2 cells	1 cell
7 cells	10 cells	2 cells	2 cells	1 cell
25.2 V	28.8 V	7.2 V	7.2 V	3.6 V












Volume	15 cm <sup>3</sup>	11,7 cm <sup>3</sup>	1,8 cm³	1,0 cm <sup>3</sup>
Cell Area (ea.)	3,5 cm <sup>2</sup>	3,5 cm <sup>2</sup>	1,4 cm <sup>2</sup>	0,4 cm <sup>2</sup>
Spec. Current	235 mA/cm <sup>2</sup>	187 mA/cm <sup>2</sup>	150 mA/cm <sup>2</sup>	80 mA/cm <sup>2</sup>
Rec. Max. Power	3100 mW	2800 mW	1400 mW	140 mW

## Recommendations for Fuze Electronic Design



- Timing of Power Electronic Fuze Parts
  - Controlled Charge of Ignition Capacitors
  - Start Up of µController (delayed)
  - Switched Sensor Start
- No "Big" Capacitors on Power Inlet (DC/DC-Converter)
- Small Power Buffer (Capacitors) for Actuators
- Moderate Power Consumption can lead to Standard Fuze Battery
- Involve D&EP early in Power Consumption of your Fuze Electronic



### **Future developments**



- 1 & 2 cell batteries for high spin and high acceleration application
- Development on super quick in barrel activation batteries for artillery and naval versions
- Development of new electrode material for higher current / power application



# Thank you for your attention!

Questions?

# **Diehl & Eagle Picher Contact**



How to Contact us

Presenter Roland Hein

Mail Diehl & Eagle Picher GmbH

Fischbachstrasse 20

90552 Roethenbach ad Pegnitz

Germany

Phone +49-911-957-2589

• Fax +49-911-957-2830

Email Roland.Hein@diehl-eagle-picher.com

Web www.battery.de