

PRELIMINARY DRAFT V2 June 7th

Detonation Transfer Reliability – Axial and Angular Alignment Evaluations using a Neyer Statistical Sensitivity Approach

David Pray

May 11, 2021

Transfer Reliability Background

System level detonation transfer reliability

- ▶ Ordnance to ordnance (Donor to Acceptor)
- ▶ Critical to system performance

RCC 319 –Range Commanders Council

Flight Terminations Systems Commonality Standard

- ▶ Section 4.35.3 – Detonation Flier Plate Ordnance Transfer Systems
 - ▶ .999 Reliability at 95% Confidence Level

Transfer Reliability Background

RCC 319 (.999 Reliability at 95% Confidence Level)

- ▶ 2994 tests in flight representative configuration
 - ▶ Cost prohibitive
- ▶ Testing at 4X gap, axial, angular misalignment
 - ▶ May not be practical for some systems
 - ▶ No variable data
- ▶ Statistical sensitivity method that varies critical performance parameters:
Gap, **Axial** and **Angular** alignment
 - ▶ Methods: Bruceton, Langlie, **Neyer**, etc.
 - ▶ Best Solution for variable data
- ▶ Testing must be conducted at qualification low temperatures (cold)

Neyer D Optimal

Neyer D Optimal -Sensitivity Test

- ▶ Threshold of individual unit cannot be determined
 - ▶ Detonation transferred or it did not (binary response)
 - ▶ Testing at different levels establishes the parameters of the population
 - ▶ Test levels optimized to maximize information of the population
 - ▶ Software algorithm determines “next test level”
- ▶ Reliability of system or subsystem can be predicted



Sentest™ (Neyersoftware.com)

Detonation Transfer Reliability

Test Design – Axial Offset

Fixture Considerations

- ▶ Hold donor and acceptor
- ▶ Represent system level interface
- ▶ Large adjustment range
 - ▶ Beyond detonation transfer offset limit
 - ▶ Screening Tests Recommended
- ▶ High resolution required
- ▶ Fixture may be a single use
- ▶ Sentest™ software simulations
 - ▶ Evaluate potential outcomes





Detonation Transfer Reliability

Test Design – Angular Offset

Fixture Considerations

- ▶ Hold donor and acceptor
- ▶ Represent system level interface
- ▶ Large adjustment range
 - ▶ Beyond detonation transfer offset limit
 - ▶ Screening Tests Recommended
- ▶ High resolution required
- ▶ Fixture may be a single use
- ▶ Sentest™ software simulations
 - ▶ Evaluate potential outcomes



Test Considerations

Test Temperature (cold – system defined)

- ▶ Thermal conditioning
 - ▶ Study to determine minimum soak time
 - ▶ Fixture material effects
- ▶ Test temperature -actual
 - ▶ Study to determine maximum time out of environmental chamber
 - ▶ Insulation required?

Donor material

- ▶ System representative
- ▶ From a single lot to minimize variables

Acceptor material

- ▶ System representative
- ▶ From a single lot to minimize variables

Detonation Transfer Reliability

Test Steps

Setup Software (Sentest)

- ▶ MuMin, MuMax, SigmaGuess (affects starting offset)
- ▶ Resolution, Upper and Lower Limits (fixture defined)


Setup & Test Unit 1

- ▶ Environmentally Condition
- ▶ Function
- ▶ Determine transfer success
- ▶ Enter Results of Test 1 into software
 - ▶ Neyer Software determines next offset to optimize data set

Setup & Test Unit 2

⋮

Repeat process 25 to 30 times (looking for stable data - Mu and Sigma)



Interpretation of Test Results

Tolerance stack analysis of system Interface

- ▶ Determine worst case offset

Neyer D Optimal Results for .999 reliability and 95% confidence interval (one sided)

- ▶ Offset determined

Goal

- ▶ Tolerance stack results \leq Offset required for .999 reliability and 95% confidence interval

Actual achieved reliability can be determined by setting the necessary statistical calculations in the Neyer D Optimal software

Interpretation of Test Results:

Axial Offset Example:

Tolerance stack (system interface between donor and acceptor)

- ▶ Worst case offset = .015”

Neyer D-Optimal Results (30-unit study)

- ▶ $\mu = .082$ ”
- ▶ $\sigma = .0096$ ”
- ▶ .999 Reliability at 95% Confidence Interval = .021”

$.015 \leq .021$ Therefore reliability goal is met

Summary

RCC 319 .999 Reliability at 95% Confidence Level

- ▶ Statistical sensitivity method that varies critical performance parameters:
Gap, Axial and Angular alignment
 - ▶ Success demonstrated by use of **Neyer-D Optimal**
- ▶ Fixture Design that permits adjustment of critical performance parameters is required

Detonation Transfer Reliability



David Pray

Energetic Components Engineer

(937) 865-3011

david.pray@excelitas.com

John Sparkman

Mechanical Engineering Leader

(937) 353-2265

john.sparkman@excelitas.com

Al Starner

Product Line Director

(937) 865-3544

allen.starner@excelitas.com

Roy Streetz

VP, Advanced Electronic Systems

(937) 353-2242

roy.streetz@excelitas.com

About Excelitas Technologies

Excelitas Technologies is a global technology leader focused on delivering innovative, customized solutions to meet the lighting, detection and other high-performance technology needs of OEM customers.

From analytical instrumentation to clinical diagnostics, medical, industrial, safety and security, and aerospace and defense applications, Excelitas Technologies is committed to enabling our customers' success in their specialty end-markets. Excelitas Technologies has over 7,300 employees in North America, Europe and Asia, serving customers across the world.

EXCELITAS

TECHNOLOGIES

ENABLING THE FUTURE THROUGH LIGHT

WWW.EXCELITAS.COM